

Griffen's Clock Parts and Supplies



The Herschede Hall Clock Company

P.O. Box 857, North Plains, OR 97133

Herschede Hour Hand Adjustment Instructions

The Herschede hour hand may require some adjustments to fit the Herschede-made movements. The movement hour tube may vary on the Herschede-made movements due to manufacturing tolerances and wear of the parts over the decades of use.

These instructions are to assist you in adjusting the hour hand for your Herschede-made movement.

1. The hour hand bushing is to be placed on the Herschede hour tube assembly shaft. The hour hand bushing slot fits over the hour tube side screw and the hand should be pushed securely onto the shaft.
2. The hour hand bushings are on the hour hand in such a manner that the hand can be carefully moved to set the hour hand position. The hour hand may need to be removed and adjusted to the bushing in order for the time to be set correctly.
3. After the hour hand has been positioned properly to the movement time, then the hour hand can either be left alone if firmly attached or a slight tapping of the hour bushing to the hour hand may be required. Be careful to not bend the bushing tube as it will not fit back on the hour tube if bent.
4. Note, the hour hand must be snug to the hour hand bushing such that if the hour hand is moved it does not slip in the bushing.